

# Can Am Spyder Floorboards Installation Instructions

## Part # CS001FFB

Thank you for choosing SFB Racing Floorboards. The following instructions are to aid you in the installation. If for any reason you are uncomfortable with the installation please consult a trusted mechanic, or contact us directly at (905) 899-4725 10am-5pm EST and we will be happy to help with any questions that may arise.

1. Locate 6mm circlip on foot peg pin and remove
2. Remove pin, if pin is tight you may need a drift and hammer to remove.  
(the pin and circlip will be reused on floorboard installation)
3. Remove stock foot peg and spring (these parts will not be reused)
4. Examine foot peg mounting casting for any ridges caused by the foot peg embedding into the casting if present, a small file may be used to remove only the raised area. The floorboard installation requires a flat surface.
5. Install supplied 5 x 30mm bolt into floorboard mount as pictured.



6. Holding the bolt up from underneath install floorboard into foot peg mounting position.
7. Re-install factory pin set aside in step 2 and install circlip.
8. Align 5mm tapped hole in the bottom of the replacement foot peg with the 5mm bolt that was installed in step 5.
9. Using a 4mm Allen key tighten bolt, to draw down the replacement foot peg as pictured only snug bolt at this time, it will tightened later.



10. Install the remaining supplied 5 x 10mm bolt in the rear of the foot peg replacement
11. Both of the 5mm bolts installed can now be torque to 5.0 N-m or 44 lbf-in.
12. Repeat steps 1 through 11 for the opposite side.
13. Before riding we ask you at this time to check the function of your brake pedal, be sure that there is no interference between the brake pedal and floorboard mounting arm. With maximum force applied to the brake pedal there should be no contact, if contact is made your brake system will need to be serviced by an authorized Can-AM Spyder Service Department.  
**DO NOT RIDE YOUR SPYDER UNTIL THIS PROBLEM IS RECTIFIED.**  
If you are unclear in any way with this step or any of the previous steps please contact us at (905) 899-4725.

### Warning

As with all modifications to your Spyder, caution should be used on the first ride until you become familiar with the changes in riding position.

### Warranty

SFB Racing Floorboards carry a 3 year manufacturing defect warranty. If you receive a product that is defective please feel free to call us at (905) 899-4725 and we will at our discretion repair or replace the said product.

**SFB Racing.net**

SFB Racing is a division of Drysdale Precision Mfg. Inc  
31180 Garringer Rd. Wainfleet On L0S 1V0

Phone 1 905 899 4725

Fax 1 905 899 4904